



Generation	Code 1	Code 2	Example Code1	Example Code 2
Gen1	C XXXX	L XXXX	C 1208	L 1458
Gen2	C2 XXXX	L2 XXXX	C2 1348	L2 1208
FADE	C3 XXXX	L3 XXXX	C3 1587	L3 1642

Gen2 is always marked with number 2 after the letter. FADE is always marked with number 3 after the letter.

Same Code sharing for MTB/Road and Boost/ Non Boost and 6bolt/CL