



When centering, the spoke must be countered from the inside with a centering wrench.

**Important:** do not hold the spoke against the carbon area, otherwise the spoke may break.



Centering is done from the outside with a special key.

Secure the spokes in the hub with Loctite 243 to prevent loosening. Add Loctite to the thread before screwing the spoke in the hub. This step is only necessary on road hubs, not on MTB hubs.

After centering, glue the spoke and nipple with Loctite 290.